

## 6. General Specifications:

Currency and  
Protocol:

See Software Description Document

Electrical  
Specification:

Voltage	Max. Operating Current	Max. Current
24 V DC	2.5 A	4.0 A

Use only current limiting CSA or UL approved Power Supply.

Operating

Temperature:

-0 to +60 Degrees Celsius

Weight:

18.2 kg (Without Cassette)

Weight of Cassette:

2.3 kg

Features:

Multi-Width Validating Head  
End Switch for the Cassette  
Metal Coin-Proof Bezel  
Lockable Recycling Storage  
One Recycling Cassette  
Outdoor Application (Coated Boards)

Items

Enclosed:

Bill-to-Bill Currency Management System  
User Guide  
Software Description  
Prepare to Operation Instruction OPT-BB-INST-4  
Security Locks Installation Instruction OPT-BB-INST-5  
Mounting Kit for Lock Installation OPT-MKBB-LOCK  
Mounting Kit for Grounding Connection OPT-MKBB-GND  
Mounting Kit for Dispensing Cassette OPT-MK-BBD  
Wiring Harness OPT-HS-BB-CCNET

Optional:

Sensor Box Extractor OPT-HW-FT01  
Mounting Kit Outlet Connector OPT-MKBB-EA  
CCNET Interface Description OPT-MAN-CCNET



1743 Linneman Road, Mount Prospect, IL 60056 USA  
PHONE: 1-847-952-5932 or 1-800-239-7017

[bill-to-bill@suzohapp.com](mailto:bill-to-bill@suzohapp.com)

<http://www.suzohapp.com/Bill-to-Bill>



© 2017 SUZOHAPP



## Bill-to-Bill Currency Management System

### MBB-5132

The Part Number on the Label includes Hardware Part Number and Software Part Number.



## 1. Assembly Contents:

Unit	Part No.	Description
Validating Head	MFLV-9013	With Multi-Width Centering Mechanism
Sense -A- Click	FLS-1706U FLS-1706L	Sense-A-Click Sensor Packs
Bezel	MFLB-7102	Metal Coin-Proof Bezel with GND
Housing	BBH-5514	1000, RFID
Chassis	BBC-0110	Holder for 3 Recycling Cassettes, Dispensing Cassette and Path Switch
Dispensing Cassette	BBD-0310	Metal Bezel with GND
Recycling Cassette	BBR-0111	Lockable, Storage from 90 to 110 Bills
Path Switch	BBS-0110	Separating of Bills
B2B Power Interface	BBP-5730	24 V DC, RS-232 with RFID
Box Control Unit	BCU-0001	Stacking of Bills into Cash Box

## 2. DIP Switch Setting:

DIP switches may be accessed by removing the Validating Head and opening the transparent cover at the rear. See Software Description for correct denominations and settings.

SW No.1	ON State	OFF State	Default
SW 1.1	Bill Type 1 Enable	Bill Type 1 Disable	ON
SW 1.2	Bill Type 2 Enable	Bill Type 2 Disable	ON
SW 1.3	Bill Type 3 Enable	Bill Type 3 Disable	ON
SW 1.4	Bill Type 4 Enable	Bill Type 4 Disable	ON
SW 1.5	Bill Type 5 Enable	Bill Type 5 Disable	ON
SW 1.6	Bill Type 6 Enable	Bill Type 6 Disable	ON
SW 1.7	Bill Type 7 Enable	Bill Type 7 Disable	ON
SW 1.8	Bill Type 8 Enable	Bill Type 8 Disable	ON


SW No.2	ON State	OFF State	Default
SW 2.1	Four Way	One Way	ON
SW 2.2	Reserved	Reserved	ON
SW 2.3	Reserved	Reserved	ON
SW 2.4	Service	Host Communication	OFF

## 3. Interface Connector Pinout:

Mating Connector:

Socket 43645-1000 (Molex)

Contact 43030-0008 (Molex)



Terminal	Circuit
1	+24 V DC
2	+24 V DC
3	0 V DC
4	0 V DC
5	GND
6	GND
7	TxD
8	RxD
9	M – RES
10	COMM GND

## 4. Diagnostics:

Chart below lists the validator malfunctions, as indicated by the flashing bezel light:

No. of Consecutive Flashes	Malfunction
1 Green/ Red	COM Port CRC error
2 Green/ Red	Internal CRC error
3 Green/ Red	Improper Memory Stick
4 Green/ Red	Memory Stick is absent
5 Green/ Red	Improper type of Memory Stick
6 Green/ Red	Download error

## 5. Grounding:

1. Ground terminal must be connected to the host machine ground.
2. Use Mounting Kit OPT-MKBB-GND.
3. Connect grounding cable to screw shown. A copper wire of 14 - 12 AWG may also be used.

