

## INSTALLATION INSTRUCTIONS FOR PRISM

### **MODEL LB5001**

#### IGT S2000 Lower PANEL

1. Open front door access (belly glass)
2. disconnect florescent fixture
3. Remove mounting screws of fixture and remove fixture.
4. Install new LED panel in slots of frame and install two screws as shown.
5. Disconnect input harness going to ballast. Connect this power to LED panel cable

