

Figure 1
Exploded View of Cabinet

Item Number	Description	Part Number
8	Housing, L/R Speaker-Gen	400026-001
17	Arms, Hood, L&R-Gen	400112-001
14	Bezel, front Rhapsody	400115-001
20	Lock Bar	400036-001





Figure 2
Exploded View Main Components

Item Number	Description	Part Number
1	Bose 141 Spkrs (pair)	700021-001
	Bose 141 Spkrs (4 pack)	700021-004
2	MET, 141/151 Brkt (single)	401077-001
4	Mon.17" LCD/ELO Rhap	300323-001
	Bracket Kit 17" Kit ELO Rhap	400534-001
	Mon.15" LCD/ELO Gen/Mae	300342-001
	Bracket Kit 15" ELO Genesis	400538-001
	PSU, ELO Monitor 15", 17"	300508-001
	Touchgl. 15" LCD/GT Gen 4mm	300227-002
9	Mgr,Ibutton PCB Gen/Rhap	300139-001
10	Manager PCB with I Button	300140-001



*Figure 3
Exploded View of Rear Door Assembly*

Item Number	Description	Part Number
6	Zone 2 amp, Genesis/Rhap	300034-001
9	Fan, Genesis 110V	300060-001
10	I/O Board assy / Pwr Dist PCB	300031-002
11	Power Dist PCB Gen/Rhap	300145-001
12	Transfmr rear Gen/Rhap	300151-001
13	Zone 1 amp, Genesis/Rhap	300033-001




Figure 4
Exploded View of Front Drawer and Payment Means Assembly

Item Number	Description	Part Number
8	Coin bag, genesis	400040-001
12	Coin Acceptor, Genesis	400052-001
14	Bezel, Pymnt means, RHAP	400151-001
	Payment bezel, Grey, Genesis	400037-001
19	Fluoresent Light Transformer	300032-001
27	Slide Rail, Rhapsody	400290-001