



Field Bulletin

- SC Series Bill Validators
- PPM downloading to SC series

Bulletin #:	FG00506
Bulletin Date:	April 18, 2006
Subject:	PPM downloading instructions
Affected Model(s):	All SCXXXX models

Summary:

This bulletin describes the proper PPM sequence of when you can disconnect the USB harness from the SC series bill validator when performing a software download.

Detail:

When downloading from a PPM to a SC series bill validator the following sequences needs to be followed in order to have a successful software download.

- After connecting the USB harness from the PPM to the SC series bill validator
- Press the Yellow button located on the PPM.
- The PPM will have a flashing Red and solid Green LEDs. (Fig.1)
- The SC series bill validator will perform a run and stack
- After the run and stack has been completed look at the PPM and **wait for the LEDS to turn OFF Before disconnecting from the SC series bill validator. (Fig.2)**



Fig.1



Fig.2

Questions should be directed to MEI Technical Support at 1-800-345-8172 or our web site: www.meiglobal.com

Note: If the PPM is disconnected from the SC series bill validator before the PPM's LED's have turned off the SC acceptor module will lock up. (All MMI LED's on solid). If this occurs you must cycle power to the SC series bill validator, then reconnect the PPM and perform another download following the procedure above.

Action:

Contact your local MEI or AESI representative for any further assistance.

AESI Contact Information

6285 S. Mojave Road, Suite E
Las Vegas NV. 89120
Toll free: 866-736-AESI (2374)
Phone: 702-597-4840
Fax: 702-597-4837