Security Lock Installation

In order to install the security locks, open the lid, remove the plastic lock and plug. Follow the steps as shown in the diagrams below.

Variant 1:

Mounting Kit for 2 Locks OPT-MK-FLC Includes: Cam 5110032 2 pcs. Washer 5110034 2 pcs. Washer 5110034-01 4 pcs. Washer 5110035 4 pcs. Two Locks are

(Only for installation of the lock A = 5/8 " Ø19.05 [3/4"] 15.88 [5/8"] Washers (1-2 pcs.) A=11/6"±1/16" 0.6875+0.01" or 1.125+0.01

Hex Nut

(5110032)


*Washe

(5110034-01)

Variant 2

Recommended

Mounting kit OPT-MK-FLC1 One for Each Lock Must be Ordered as Option Kit Includes: Cam 5106034 Nut 5310021 Washer 5310022 Two Locks are Recommended





1743 Linneman Road, Mount Prospect, IL 60056 USA PHONE: 1-847-952-5932 or 1-800-239-7017

bill-to-bill@suzohapp.com


http://www.suzohapp.com/Bill-to-Bill

© 2017 SUZOHAPP



Cashbox with Folding Handle

FLC-003 FLC-103 FLC-503 FLC-603





Specifications:

(5110034) and/or

	FLC-003	FLC-103	FLC-503	FLC-603
Bill Capacity	600	600	1000	1000
Bill Width mm	62-82	62-82	62 - 82	62-82
Bill Length mm	120 – 160	120-172	120 – 160	120-172

Note: Open the cashbox to remove the shipping carton and ensure the holder is flat and free to move.





Incorrect