



## **LCD Screen Protector**

49-5888-32 30-32 Inch LCD Screen Protector

49-5888-37 36-37 Inch LCD Screen Protector

49-5888-42 40-42 Inch LCD Screen Protector

### **Installation and Care Instructions**

- ✓ Carefully open the box and remove the LCD Screen Protector. Be cautious using a knife to open the box as you may scratch the product. Save the cleaning instruction sheet that comes with the product for future reference. Remove the felt pads and straps from the box and put them off to the side for the moment.
- ✓ Using your fingernail, gently pull back the corner of the protective paper that covers the LCD Screen Protector and protects it from scratches during shipping. Remove the protective paper on both sides. Do NOT use a tool or knife to remove the protective paper as you may scratch the LCD Screen Protector.
- ✓ Place the LCD Screen Protector unit on your LCD. The side with the bend is to be placed on the top of the LCD. It should be centered on your LCD. Determine the best location in the four corners of the LCD Screen Protector to stick the felt pads (not over buttons or covering the picture area). The pads keep the LCD Screen Protector a 1/4" off your LCD surface. The pads are an essential part of its protection system. Ensure that its felt spacers are pressing against the sides (Bezel) of the LCD, not the picture area, as this may damage the LCD. Remove the LCD Screen Protector and stick the felt pads to the back side of the LCD Screen Protector.
- ✓ Place the LCD Screen Protector back on your LCD (centered) and feed one end of each Velcro™ strap through the top slots and hook it back onto itself. Drape the straps down the back of the LCD. The top edge of the LCD supports the LCD Screen Protector.
- ✓ Feed the straps from the back of the LCD through the slots at the bottom of the LCD Screen Protector and attach the Velcro™ to itself gently pulling the LCD Screen Protector tight to the LCD. There is no need to use a lot of force to accomplish this. The weight of the Screen Protector is supported by the top of the LCD.

### **Cleaning LCD Screen Protector:**

The continued optical clarity of the LCD Screen Protector depends on how you care for it. The LCD Screen Protector should be cleaned with clean, lukewarm water or a good acrylic cleaner and a micro fiber cloth. DO NOT use window cleaning products that contain alcohol or ammonia as they will haze the LCD Screen Protector over time.