

Pool Table Mini-Mover



Here's how it works!



Position the **Mini-Mover** at the middle of the pool table and engage the clamps. The clamps secure the mover to the table. The **Mini-Movers** rails are padded to protect the table.



Tip the table up onto the Mini-Mover. *For best results, remove leg levelers before tipping.*



The **Mini-Mover** has six wheels. The two, middle wheels are larger than the four outer wheels. This makes the **Mini-Mover** extremely maneuverable. You can actually spin the Mini-Mover and pool table around on the two middle wheels.

Loading onto a truck is as Simple as 1, 2, 3!

To get things started, tilt the **Mini-Mover** and the pool table on the two back and two middle wheels. This will lower the back end and raise the front. Now roll the **Mini-Mover** and the pool table onto the liftgate. As you can see the front wheels and the middle wheels of the **Mini-Mover** are both on the liftgate. The weight is lifted by the lift-gate, not the operator. The operator only balances the load. With the gate raised the table rolls right in. If the legs of the table are removed, you can put two **Mini-Movers** and pool tables on a single pickup.



For Safety over rough terrain.

Over rough terrain you can secure the pool table onto the **Mini-Mover** by strapping the table to the **Mini-Mover** using the conveniently located strap anchors.

