

# Usher in the NEW YEAR

with Pushbuttons, Screens and More!



**Gamesman Large Rectangle Pushbutton for Konami**

Part Number: **GPB540**


- GPB540 For Konami games
- Large rectangular
- Unique snap-fit eliminates the need for a locking nut
- Black Bezel
- 12v LED



**Gamesman Small Square Pushbutton for Konami**

Part Number: **GPB510**

- GPB510 For Konami games
- Small square
- Unique snap-fit eliminates the need for a locking nut
- Black Bezel
- 12v LED



**20.38" 3M Touch Screen with Novram for IGT 98-0003-4250-5**


Part Number: **49-1084-00**

- Old 3M number 17-9830-206-01
- Used on IGT G20 bar tops and Upright games
- No controller included
- Connects with EXII controllers

Contact Your Sales Representative to Order Now!

# Usher in the NEW YEAR

with Pushbuttons, Screens and More!



**19.42" 3M Microtouch Cleartek2  
Flat T/S USB & Serial Contrlr**

Part Number: 49-0505-00

- 3M Dual Controller
- Works on both USB and Serial
- 98-0003-3819-8 SCT3250 19" sensor with mated dual mode EX113 controller
- Direct replacement for the Serial model:  
SUZOHAPP PN 49-2850-00 (3M PN 17-8891-223)
- Direct replacement for the USB model:  
SUZOHAPP PN 49-2851-00 (3M PN 17-8891-226)



**Interlock PB C&K DS2D6CQ1, 10A  
Push-Pull .187 X .020 Term.**

Part Number: 53-7030-CK

- Terminal = .187 x .020
- 10A Push-Pull
- Same terminal thickness as Cherry 53-7030-00
- 6 terminals



**Bally Twinstar Complete**

Part Number: L21C3AT3BYNCRPX



**Bally I-Deck  
LCD Button Display**

Part Number: 219621-N-CRPX

- Fully rebuilt using all new components
- 90 day warranty

Contact Your Sales Representative to Order Now!