TFT ANALOG LCD MONITOR SPECIFICATIONS

MT26W-153A SUZO-HAPP P/N 49-2861-00

SUZO-HAPP

Ver.090316

<u>Contents</u>

PRODUCT	2
Contents	2
Features	2
Power saver	
Plug & play	2
SAFETY	3
Electrical	3
Common	3
SET UP YOUR LCD MONITOR	4
Installation	4
Screen Adjustments	4
OSD Control	5
TROUBLE SHOOTING	.8
MAINTENANCE	.9
SPECIFICATIONS	.10
SUPPORT PC TIMING	11
MINI OPEN FRAME OUTER DIMENSION	12

PRODUCT

Contents
 The Accessories in this LCD Monitor Model.Accessory Box:I. VGA cable X 1Power Cord X 1User's manual X 1CGA Cable(Optional)Features
 High Brightness.Fast response time.Power Saver.Low electromagnetic wave and power saver.Safety certifications.

Note : Save the original box and packing material for future shipping needs.

Power saver	
	• Power control system, also called (Power Saver), is installed inside the LCD Monitor.
	If the monitor has not been used for a certain period of time, the system will turn the monitor to low voltage mode to save power. Slight moving or any click will return to the original image.
	The VGA card inside the computer handles Power Saver. You can use computer software to set the function.
	The LCD Monitor is compatible with EPA ENERGY STAR and N TEK if used with a VESA DPMS computer.
	To save power, turn off the power of the LCD monitor when not in use.
Plug & play	
	The new VESA Plug and Play function is used which eliminates the complicated and time-consuming installation process.
	You can use the Plug and Play system without encountering usual installation problems. Your computer system can easily identify and automatically adjust the monitor.
	The LCD Monitor uses Display Data Channel (DDC) to send Extended Display Identification Data (EDID) to the computer system, so the computer system can be set to monitor auto adjust.

SAFETY

Note: Please note the following safety precaution before using this monitor.

Electrical	
Sure the Voltage	Before connecting the AC power cord to the DC adapter socket, make sure that voltage of the DC adapter is suitable for local power.
Electrical Shock	Do not insert any metal object into opening on the LCD monitor casing to prevent electrical shock.
	To prevent electrical shock, do not touch the interior of the LCD monitor. Only a qualified technician should open the casing of monitor.
	If the power cord is damaged, do not use the LCD monitor. Do not place any object on the power cord, and place the power cord away from crowded areas.
	While pulling the LCD monitor plug away from the socket on the wall, hold the plug not the power cord.
	Do not expose the LCD monitor in the rain or somewhere closed to the water (such as in the kitchen, near the pool).
	If the LCD monitor is dampened, please unplug the power cord and contact Service Center.
Unusual condition	If the LCD monitors functions improperly, especially when making unusual noise or spreading strange odor, unplug it immediately and contact service center.
Common	
Monitor and Screen Care	Avoid touching the screen with your fingers or any tough objects. Oil from the skin is difficult to remove, and touching objects to the screen may damage the panel. It is suggested to clean the monitor by first turning it off and using a soft, dry cloth.
	The LCD monitor should be placed in areas with low humidity and less dust. Please watch out for environmental conditions on humidity and ventilation.
	The LCD monitor should be kept away from heat sources and irradiation. For example: kitchen, oven or direct sunlight and etc.
	• To reduce glare, avoid placing the monitor in a place that receives direct sunlight.
	Avoid letting small children play with monitor. The frequent touching of the panel will cause panel to look dirty and will affect the quality of the brightness if too dirty.
	If moving the monitor, please handle with care when unplugging and moving it.
	• Do not place items over the monitor when placing and adjusting the LCD monitor.
	If the LCD monitor is not in use for a long time, please unplugit and restore it into the proper package, the original carton & packaging stuffs are preferred.
	The opening on the LCD Monitor casing is for the purpose of ventilation. To prevent overheating, the openings should not be blocked or covered. Do not place the LCD monitor on a bed, sofa, blanket or other soft surfaces; or else the soft objects will block the openings of the LCD monitors.
	If you place the LCDMonitor on abookshelf or other airtight spaces, it's essential to leave a space of 4"(10cm) distance between the Monitor and the hard surface.
Clean screen	Ensure the area around the LCD monitor is clean and free of moisture. Please refer to [Maintenance] chapter for normal maintenance practice.

SET UP YOUR LCD MONITOR

Installation Notes	Note : Please read last section " Safety" before you install the LCD Monitor. Please note the instruction below prior to installing your LCD monitor.
Installation Position	Choose a position where the reflection of light is minimal and away from a window for maximizing the quality of the screen image.
	It is important to keep 30 cm between the LCD monitor to minimize eyestrain.
Workstation Height	• Position the LCD monitor slightly above your horizontal vision as you are sitting.
Angle of Vision Quick Installation	Tilt either forward or backward for the most comfortable viewing angle. This LCD monitor supports connection to a computer or workstation. The steps are described as Quick Setup.
S	After installation, please refer to "Auto Adjust" for automatic adjust procedures.
Screen Adjustments	
Auto Adjust	Though your computer system can identify the new LCD monitor system, the Auto Adjust function can be as to enhance the display. To enter adjust mode, please refer to "OSD Control".
	Turn the computer and LCD monitor on.
	Press 'Auto' button to start Auto Adjust.
	The LCD monitor will start the Auto Adjust process automatically for 10 consecutive seconds, where you will notice the image change as the Auto Adjust is working.
Self Test Function Check (STFC):	Your LCD monitor provides a STFC function, through which you can check whether the LCD monitor functions are working properly.
	If your LCD monitor is properly connected, but there is no image showing and the indicator light keeps orange, please follow the steps below to start STFC.
	Shutdown computer and LCD monitor. Unplug the signal connector from the back of computer. Turn the LCD monitor on.
	If the image connector is disconnected or damaged, the image shown on following figure will also appear during normal operation.
	NO SIGNAL
	Turn off the LCD monitor and reconnect signal cable, and then turn the computer and LCD monitor on.
	If the LED of the LCD monitor is an orange color after completing the steps above, please check your VGA card and computer system. Your monitor should be operating properly.

OSD Control	Thanks to the user-friendly design of OSD (On Screen Display), you can adjust your monitor by the keypads in the front of the monitor.					
		654321				
	1	Power Switch	Power On/O)ff		
	2	LED	Power Indicator			
	2		Green:Normal			
			Red:Power Saving			
			Off:Power O		9	
	3	Menu	Show OSD	///		
	4	+		when	OSD is shown	
	5	-			OSD is shown	
	6	Auto/Esc			imize positions,phase&clock when OSD	
					D when OSD is shown	
VGA Signal Connector				50 40 10 ⁰ 1 150 140	0 30 20 10 0 80 70 60 0 30 120 110	
Connector						
			Pin 1		Analog Red Input	
			Pin 2		Analog Green Input	
			Pin 3		Analog Blue Input	
			Pin 4		Ground	
			Pin 5		Digital Ground	
			Pin 6		Analog Red Ground	
			Pin 7		Analog Green Ground	
			Pin 8		Analog Blue Ground	
			Pin 9		Ground	
			Pin 10		Sync Ground Ground	
			Pin 11 Pin 12			
			Pin 12 Pin 13		SDA (DDC Data) H. Sync or H+V Sync.	
			Pin 13		V. Sync	
			Pin 15		SCL (DDC CLK)	
			1 11 10			
CGA Signal Connector (Optional)		1 2 3 4 5 6 7 8 9 10			■ ■ ■ ■ ■ ■ 5 6 7 8 9 10	
		Di	n1	<u> </u>	A Apolog Rod Input	
					CGA Analog Red Input	
			n2	CGA Analog Green Input		
		Pi	n3	CGA Analog Blue Input		
		Pi	n4	Ground		
		Pi	n5	V Sync		
		Pi	n6		-V,H Sync	
			n7		Connection	
			n8		ound	
			n9		Sync	
		Pi	n10	H+	-V,H Sync	

Operate Explanation Y

Your LCD has been adjusted to its optimal status before shipment. You can also adjust the image in accordance with the following illustrations and steps.

- Press the "Menu" button to start the OSD feature.
- Click the "+" or "-" button to select the function to be adjusted.
- Click the "Menu" button to access into the function to be adjusted.
- Click the "+" or "-" button to change the current setting of the function.
- To exit the OSD menu or go back to the previous action by clicking the "ESC" button. It will save the change automatically.
- To repeat above steps for changing the setting of other functions.

1280x1024 60.1Hz			
Contrast Brightness Sharpness Color Temperature User RGB Image Alignment Reset	: 6500K		
+¦+ Select/Adjust	Menu:Enter		

Notes

- The OSD disappears several seconds after you stop pressing the buttons while performing an adjustment.
- Any changes are automatically saved in the memory when the OSD disappears. Turning off the power should be avoided while using the menu.
- Adjustments for clock, phase and positions are saved for each signal timing. Except for these adjustments, all other adjustments have only one setting which applies to all signal timings.
- The color will change from white to pink while the function is selected.

Adjustment of Screen					
Screen	Mode		Description		
Function Definition	Image	Contrast	Adjust the contrast of the image.		
	Setting	Brightness	Adjust the brightness of the screen.		
		Sharpness	Adjust the picture sharpness.		
		Color temperature	User/6500/7500/9300.		
		User RGB	Adjust red/green/blue gain.		
		Image Alighthent	Adjust picture position.(V-size,H-size,)		
		Reset	Restore to factory settings.		
	Feature	Auto Color	Auto adjust the screen color.		
	Controls	Screen Test	Screen Test.		
		Language	Adjust the language.		
		Input Source	Adjust the input source.		
		OSD Timer	Adjust the OSD timer.		

TROUBLE SHOOTING

	Check the information in this section to see if the problems can be solved before requesting repair.				
	Note [:] The consumers are only allowed to solve the problems described as below. Any unauthorized product modification, or failure to follow instructions supplied with the product will end the warranty immediately.				
No image	Make sure power button is ON.				
	Check whether the LCD monitor and computer power cords are plugged and whether there is a supply of power.				
No Signal Input	Check the signal connection between the computer and LCD monitor.				
"Out Of Range"	Check the computer image output resolution and frequency and compare the value with the preset values (Please refer to [Appendix-Display Mode]).				
Fuzzy image	♦ Adjust Phase.				
lmage too bright Image too dark	 Adjust brightness and contrast by OSD. 				
lrregular image	Check the signal connection between the computer and LCD monitor.				
	Perform Auto Adjust.				
Distorted image	Reset the LCD monitor. (perform the "Recall" function by OSD)				
	Take offextra accessories (such as signal extension cord).				
Image is not centered	 Use OSD Image Menu to adjust H. Position and V. Position. 				
Size is notappropriate	Check image size setting.				
	Perform Auto Adjust.				
Uneven color Color too dark Dark area distorted White color is not white	Use OSD Color Menu to adjust color setting.				
Can't adjust LCDmonitor with the buttons in the front. The other problem	Please contact the stores where you purchased the unit or service center listed at your warranty card.				

MAINTENANCE

	This product is under strict quality control in the production process. Maintaining the monitor, refer to the description as below, and is important for maximizing the display performance and product life.					
	Warring: To prevent electrical shock, do not open the LCD monitor casing. Users shall not repair the LCD monitor on their own. Users' maintenance is limited to cleaning of the parts below.					
Unplug the power	Unplug the LCD monitor from an AC socket before conducting maintenance.					
Check the cover	• Check to see if the LCD Monitor and accessories are damaged, broken, or strained.					
Clean	Never spray or pour any liquid directly onto the screen or case.					
	Avoid water or and liquid permeating into the LCD monitor or accessories.					
Cleaner	Pure water or non-ammonia, non-alcohol based glass cleaner. Do not use ketene (such as acetone), ethanol, toluene, acetic acid, methane, chloride, or abrasive detergent to clean the monitor because those chemicals					
Screen	can damage the LCD monitor. To clean your LCD monitor screen, use water or mild cleaner, as above, to gently moist a soft, clean cloth.					
Case Accessory	If possible, use a special screen cleaner sheet or a solution suitable for static					
Conserve	If the LCD monitor is not in use for a long time, please unplug and save in original box in order to avoid any unexpected damage.					
Disclaimer	Any damage resulting from use of any cleaner that is not mentioned above is not covered under this warranty term.					

SPECIFICATIONS(MINI OPEN FRAME SERIES) * FEATURES:

- * High Brightness.
- * External OSD key board.
- * Fast response time.
- * Low electromagnetic wave and power saver.
- * RoHS compliance.

SPECIFICATIONS:

	Model	MT26W-153A	
ModelSelectionGuide		VGA+CGA	
Touch	3MTouch		
System	ELO-Touch		
	Screen Size	26.0	
LCD	Pixel Pitch(mm)	0.4215*0.4215	
Panel	Backlight	CCFL*12	
	Cell Type	MVA	
	Response	6.5ms	
	Aspect Ratio	16:9	
Viewing	Horizontal	176 [°]	
Angle	Vertical	176 [°]	
_	Input Mode	WXGA	
Video	Horizontal	15~48KHz	
	Vertical	50~64Hz	
	Resolution	1366*768	
-	Contrast Ratio	2500:1Тур	
Display	Brightness	Min 360 cd/m2	
		Typ 450cd/m2	
-	Horizontal Size	575.769	
-	Vertical Size	323.712	
-	Colors	16.7M	
-	Bandwidth	90MHz	
	Consumption	110Wmax	
		VESA-DPMS	
Power	Management	110Wmax	
		PowerDown	
		Mode =9Watts</td	
	Input	AC Power(Input110-240VAC)	
Operations	Function Key	5Key	
	OSD Adjustment	Constrast,Brightness,Phase,Clock,H-position,V-position,Exit	
In	put Signal	0.7Vpp Analog75 ohm	
	Sync	TTL Level Separate,Composite	
Windows Compatibility		Windows98/2000	
PC Interface		Analog Interface	
Si	gnal Cable	Standard VGA cable w/15-pin D-sub	
E	MI/Safety		
Operati	ng Temperature	0°C~50°C	
I	Humidity	10~85%	
Outer Dim	ension(L*W*H)mm	626x379.6x90.6	

Support PC Timing

Item	Resolution	H Freq.(kHz)	V Freq.(Hz)	Note
1	640x480@60	31.469	59.940	VGA
2	800x600@56	35.156	56.250	SVGA
3	800x600@60	37.879	60.317	SVGA
4	1024x768@60	48.363	60.004	XGA
5	1280x768@60	47.600	60.030	WXGA
6	1360x768@60	47.539	59.573	LCD
7	640x215@57	15.1	57.6	CGA
8	640x198@58	15.4	58.8	CGA
9	640x215@60	15.7	60	CGA
10	640x215@61	16.0	61	CGA
11	640x215@62	16.3	62	CGA
12	640x215@63.4	16.6	63.4	CGA
13	640x215@64	16.8	64	CGA
14	640x265@50	15.6	50.3	CGA
15	640x350@58	21.8	58.9	EGA
16	645x355@59	24.4	59.5	EGA
17	720x378@52	23.5	52	EGA
18	720x400@57	26.4	57.4	EGA

